



3-CPUDR CPU Door Installation Sheet


Description

The 3-CPUDR provides the cover and the mounting brackets for CPU modules that are installed without an LCD display module.

Installation


1. Insert the top and bottom display mounting brackets into the CPU module. See Figure 1.
2. Position the left door in its fully open position perpendicular to the CPU module. Align the hinge pins with the hinges on the left display mounting brackets then gently set the door module onto the brackets. See Figure 2.
3. Set the right door on the right display mounting brackets as described above.
4. Make sure the doors can open and shut without interference.

Figure 1: Mounting bracket installation



1. Top display mounting bracket
2. Bottom display mounting bracket

Figure 2: Door installation



Regulatory information

North American standards	UL 864, CAN/ULC-S527
Environmental class	UL: Indoor dry IEC: 3K5
EU compliance	CE
EU certificates	2831-CPR-F1080
UK compliance	UK CA 0832
EN 54	EN 54-2:1997/A1:2006 EN 54-4:1997/A1:2002/A2:2006 EN 54-16:2008

Contact information

For contact information, see www.edwardsfiresafety.com.

